

2Wire PC Port Driver Installation for Windows Computers

These instructions describe the procedure to install the Windows USB driver for the 2Wire PC Port Phonenumber 10 Mbps USB Adapter. 2Wire has two different PC Port models; this driver is for use *only* with the model that has one phone jack.

Installing the Driver (98/2000/ME/XP)

1. Power on your computer.
2. Connect the 2Wire PC Port Phonenumber 10 Mbps USB Adapter to an available USB port on your computer. Windows may auto-detect your new adapter, and the “New Hardware Found” dialog box will open.
3. Specify the path of the driver in your installation subdirectory (for example, C:\TWUSB_TEMP) to copy the driver file to your computer.
4. Click **Next**.
5. Select **Search for the best driver for my device**.
6. If you are using Windows 98 or ME, restart Windows when the driver installation is complete. If you are using Windows 2000 or XP, do not restart Windows.
7. After your computer restarts, configure the parameter settings in the “Network” configuration (if needed).



Note: Most users will not have to perform step 7, particularly if the PC Port IP address is automatically assigned by the 2Wire gateway.
